



MIC Standard Coupon Sampling Protocol

SAMPLING INSTRUCTIONS

Note: Clean latex gloves (or similar) should be used at all times when handling coupon samplers.

Installation:

1. Place coupon onto coupon holder, taking care not to touch the coupon with bare hands or tools.
2. Attach holder into access fitting and tighten the plug to secure.
3. Once installed, incubation times vary depending upon the scope of the project.

Retrieval:

1. Remove the coupon from the coupon holder, taking care not to touch the coupon with bare hands or tools.
2. Place each coupon separately into a whirl-pak bag. Affix a label to the bag and write the serial number of the coupon, its location in the line (e.g. top of line, bottom of line, 9 o'clock, etc.), the date and time of collection and the analysis requested.
4. Repeat the above for each Coupon Sampler from the site.
5. A chain of custody (COC) form must be included with each shipment of samples.

SHIPPING INSTRUCTIONS

Packaging Samples:

1. Samples should be shipped in a cooler with ice or blue ice for next day delivery. If regular ice is used, the ice should be double bagged.
2. A chain of custody form must be included with each shipment of samples. Access our chain of custody at www.microbe.com.

Shipment for Weekday Delivery:

Samples for weekday delivery should be shipped to:

Attn: Maia Rabinovich
Microbial Insights (Australia) Pty Ltd
C/O AGRF Ltd
Plant Genomics Centre
Hartley Grove
Urrbrae
SA 5064

**Please note Saturday delivery is not available.